



Stars Navigation Technologies Ltd

星航國際科技股份有限公司 www.starsnav.com / sales@starsnav.com

MTI-1 GPS receiver User Guide



MTI-1 Features


| | |
|---------------------|--|
| Architecture | SiRF starII high performance and low power consumption chip set |
| | Support standard NMEA 0183 protocol |
| | All-in-view 12-channel parallel processing |
| | SnapLock 100ms re-acquisition time |
| | Cold start under 45 seconds, average |
| | Superior urban canyon performance |
| | FoliageLock for weak signal tracking |
| | Optional build-in SuperCap to reserve system data for rapid satellite acquisition. |
| | Full-duplex RS-232 port for navigation and control messages |
| | Differential GPS capability through 2 nd RS-232 port |

Stingray(STR-1) Antenna Specifications

| <i>Electrical Characteristics</i> | |
|------------------------------------|--|
| Receiver | |
| Frequency | L1, 1575.42MHz |
| C/A code | 1.023MHz chip rate |
| Channels | 12 |
| Sensitivity | -170dBW |
| Accuracy | |
| Position Horizontal | 15m 2d RMS (SA off) 10m 2d RMS, WAAS enable(SA off) 1 ~ 5 m, DGPS corrected |
| Velocity | 0.1m/sec 95% (SA off), |
| Time | 1 microsecond synchronized to GPS time |
| Datum | WGS-84 |
| Acquisition Rate | |
| Reacquisition | 0.1 sec., average (recovery time for being interrupted) |
| Hot start | 8 sec., average (with ephemeris and almanac valid) |
| Warm start | 38 sec., average (with almanac but not ephemeris) |
| Cold start | 48 sec., average (neither almanac nor ephemeris) |
| Dynamic Condition | |
| Altitude | 18,000 meters (60,000 feet) max |
| Velocity | 515 meters/sec. (1000knots) max |
| Power | |
| Voltage supply | 3.8Vdc ~ 6.5Vdc |
| Current supply | Continuous mode: 60mA typical |
| Backup Power | Trickle power mode: 25mA typical +2.5V to +3.6V |
| Backup Current | 10uA typical |
| Serial Port | one for GPS, one for DGPS |
| Ports | |
| Electrical level | TTL level Output voltage level : 0 ~ 3.5v RS-232 level |
| Communication | Full duplex asynchronous |
| Code type | ASCII |
| GPS Protocol | SiRF binary/NMEA 0183 changeable(Default:NMEA) |
| GPS Output Message | SiRF binary >> position, velocity, altitude, status and control , NMEA 0183 >> GGA, GSA, GSV, RMC (VTG and GLL are optional) |
| GPS transfer rate | Software command setting (Default : 4800bps for NMEA) |
| DGPS protocol | RTCM SC-104, ver 2.00, type 1, 2, and 9 |
| Time Mark> (1 PPS Pulse) | |
| Level | TTL |
| Pulse duration | 100ms |
| Time reference | At the pulse positive edge |
| Measurement | Aligned to GPS sec., +/- 1us |


| | | |
|--------------------------------------|---|--|
| Active Antenna Connector | MCX ,SMA ,SMB or others OEM specified connector available,please refer to our gps antenna product | |
| Environmental Characteristics | | |
| Temperature | | |
| Operating | -30 deg. C to +80 deg. C | |
| Storage | -40 deg. C to +85 deg. C | |
| Physical Characteristics | | |

Dimension:



PCB SIDE VIEW

PCB TOP VIEW



Interface Connection

* Pin-out of the 20-pin interface connector

| PinNumber | Name | Description | Type |
|-----------|----------|--|--------|
| 1 | VANT | Antenna DC Voltage | Input |
| 2 | VDC | 3.8V~6.5V DC Power Input | Input |
| 3 | VBAT | Backup Battery | Input |
| 4 | VDC | (Shorted with pin 2) | Input |
| 5 | PBRES | Push Button Reset Input (Active Low) | Input |
| 6 | RESERVED | (Reserved) | |
| 7 | SELECT | Down-load data from RS232 to flash ROM (Reserved) | |
| 8 | RESERVED | (Reserved) | |
| 9 | RESERVED | (Reserved) | |
| 10 | GND | Ground | |
| 11 | TXA | Serial Data Output A (GPS Data) | Output |
| 12 | RXA | Serial Data Input A (Command) | Input |
| 13 | GND | Ground | |
| 14 | TXB | Serial Data Output B (No Used) | Output |
| 15 | RXB | Serial Data Input B (DGPS Data) | Input |
| 16 | GND | Ground | |
| 17 | RESERVED | (Reserved) | |
| 18 | GND | Ground | |
| 19 | TIMEMARK | 1PPS Time Mark Output | Output |
| 20 | RESERVED | (Reserved) | |

Interface description

* VANT (antenna DC power input):

DC voltage is for active antenna.

* VDC (DC power input):

This is the main DC supply for a 3.8V ~ 6.5V power module board.

* VBAT (Backup battery):

This is the battery backup input that powers the SRAM and RTC when main power is removed. Typical current draw is 10uA. Without an external backup battery or Gold-capacitor, the module/engine board will execute a cold star after every turn on. To achieve the faster start-up offered by a hot or warm start, either a battery backup must be connected or a Gold-capacitor should be installed. To maximize battery lifetime, the battery voltage should not exceed the supply voltage and should be between 2.5v and 3.6v.

* PBRES (Push button reset):

This pin provides an active-low reset input to the engine board. It causes the engine board to

reset and start searching for satellites.

*** SELECT :**

Do not connect.

*** TXA :**

This is the main transmits channel for outputting navigation and measurement data to user's navigation software or user written software.

MTI-1(TTL): TTL level , 0V ~ 3.5V

MTI-1(RS232): RS232 level

*** RXA :**

This is the main receive channel for receiving software commands to the engine board from SiRFdemo software or from user written software.

Normally this pin must be kept in high, and if you don't use this pin please connect a resistor to 3.5V to pull high.

*** TXB :**

No function as so far (Do not connect)

*** RXB :**

This is the auxiliary receive channel for inputting differential corrections to the engine board to enable DGPS navigation.

*** Time mark :**

This pin provides one pulse-per-second output from the engine board that is synchronized to GPS time.

*** GND :**

GND provides the ground for the engine board. Connect all grounds.

*** Others :**

Do not connect.

2. SOFTWARE COMMAND

2.1 NMEA Output Command

GGA-Global Positioning System Fixed Data

Table B-2 contains the values for the following example:

\$GPGGA,161229.487,3723.2475,N,12158.3416,W,1,07,1.0,9.0,M,,,0000*18

Table B-2 GGA Data Format

| Name | Example | Units | Description |
|-------------------------------|------------|--------|-----------------------------------|
| Message ID | \$GPGGA | | GGA protocol header |
| UTC Time | 161229.487 | | hhmmss.sss |
| Latitude | 3723.2475 | | ddmm.mmmm |
| N/S Indicator | N | | N=north or S=south |
| Longitude | 12158.3416 | | dddmm.mmmm |
| E/W Indicator | W | | E=east or W=west |
| Position Fix Indicator | 1 | | See Table B-3 |
| Satellites Used | 07 | | Range 0 to 12 |
| HDOP | 1.0 | | Horizontal Dilution of Precision |
| MSL Altitude ¹ | 9.0 | meters | |
| Units | M | meters | |
| Geoid Separation ¹ | | meters | |
| Units | M | meters | |
| Age of Diff. Corr. | | second | Null fields when DGPS is not used |
| Diff. Ref. Station ID | 0000 | | |
| Checksum | *18 | | |
| <CR><LF> | | | End of message termination |

1. SiRF Technology Inc. does not support geoid corrections. Values are WGS84 ellipsoid heights.

Table B-3 Position Fix Indicator

| Value | Description |
|-------|--|
| 0 | Fix not available or invalid |
| 1 | GPS SPS Mode, fix valid |
| 2 | Differential GPS, SPS Mode , fix valid |
| 3 | GPS PPS Mode, fix valid |

GLL-Geographic Position-Latitude/Longitude

Table B-4 contains the values for the following example:

\$GPGLL,3723.2475,N,12158.3416,W,161229.487,A*2C

Table B-4 GLL Data Format

| Name | Example | Units | Description |
|------------|-----------|-------|---------------------|
| Message ID | \$GPGLL | | GLL protocol header |
| Latitude | 3723.2475 | | ddmm.mmmm |

| | | | |
|---------------|------------|--|----------------------------------|
| N/S Indicator | n | | N=north or S=south |
| Longitude | 12158.3416 | | dddmm.mmmm |
| E/W Indicator | W | | E=east or W=west |
| UTC Position | 161229.487 | | hhmmss.sss |
| Status | A | | A=data valid or V=data not valid |
| Checksum | *2C | | |
| <CR><LF> | | | End of message termination |

GSA-GNSS DOP and Active Satellites

Table B-5 contains the values for the following example:
 \$GPGSA,A,3,07,02,26,27,09,04,15,,,,,1.8,1.0,1.5*33

Table B-5 GSA Data Format

| Name | Example | Units | Description |
|-----------------------------|---------|-------|----------------------------------|
| Message ID | \$GPGSA | | GSA protocol header |
| Mode1 | A | | See Table B-6 |
| Mode2 | 3 | | See Table B-7 |
| Satellite Used ¹ | 07 | | Sv on Channel 1 |
| Satellite Used ¹ | 02 | | Sv on Channel 2 |
| | | | |
| Satellite Used ¹ | | | Sv on Channel 12 |
| PDOP | 1.8 | | Position dilution of Precision |
| HDOP | 1.0 | | Horizontal dilution of Precision |
| VDOP | 1.5 | | Vertical dilution of Precision |
| Checksum | *33 | | |
| <CR><LF> | | | End of message termination |

Table B-6 Mode 1

| Value | Description |
|-------|--|
| M | Manual-forced to operate in 2D or 3D mode |
| A | 2D automatic-allowed to automatically switch 2D/3D |

Table B-7 Mode 2

| Value | Description |
|-------|-------------------|
| 1 | Fix Not Available |
| 2 | 2D |
| 3 | 3D |

GSV-GNSS Satellites in View

Table B-8 contains the values for the following example:

\$GPGSV,2,1,07,07,79,048,42,02,51,062,43,26,36,256,42,27,27,138,42*71

\$GPGSV,2,2,07,09,23,313,42,04,19,159,41,15,12,041,42*41

Table B-8 GSV Data Format

| Name | Example | | Description |
|---------------------------------|---------|--|---------------------|
| Message ID | \$GPGSV | | GSV protocol header |
| Number of Messages ¹ | 2 | | Range 1 to 3 |
| Message Number ¹ | 1 | | Range 1 to 3 |
| Satellites in View | 07 | | |

| | | | |
|--------------|-----|---------|--------------------------------------|
| Satellite ID | 07 | | Channel 1(Range 1 to 32) |
| Elevation | 79 | degrees | Channel 1(Maximum90) |
| Azimuth | 048 | degrees | Channel 1(True, Range 0 to 359) |
| SNR(C/No) | 42 | dBHz | Range 0 to 99,null when not tracking |
| | | | |
| Satellite ID | 27 | | Channel 4 (Range 1 to 32) |
| Elevation | 27 | Degrees | Channel 4(Maximum90) |
| Azimuth | 138 | Degrees | Channel 4(True, Range 0 to 359) |
| SNR(C/No) | 42 | dBHz | Range 0 to 99,null when not tracking |
| Checksum | *71 | | |
| <CR><LF> | | | End of message termination |

1. Depending on the number of satellites tracked multiple messages of GSV data may be required.

RMC-Recommended Minimum Specific GNSS Data

Table B-10 contains the values for the following example:

\$GPRMC,161229.487,A,3723.2475,N,12158.3416,W,0.13,309.62,120598,,*10

Table B-10 RMC Data Format

| Name | Example | Units | Description |
|---------------------------------|------------|---------|----------------------------------|
| Message ID | \$GPRMC | | RMC protocol header |
| UTC Time | 161229.487 | | hhmmss.sss |
| Status | A | | A=data valid or V=data not valid |
| Latitude | 3723.2475 | | ddmm.mmmm |
| N/S Indicator | N | | N=north or S=south |
| Longitude | 12158.3416 | | dddmm.mmmm |
| E/W Indicator | W | | E=east or W=west |
| Speed Over Ground | 0.13 | knots | |
| Course Over Ground | 309.62 | degrees | True |
| Date | 120598 | | ddmmyy |
| Magnetic Variation ² | | degrees | E=east or W=west |
| Checksum | *10 | | |
| <CR><LF> | | | End of message termination |

SiRF Technology Inc. does not support magnetic declination. All “course over ground” data are geodetic WGS48 directions.

VTG-Course Over Ground and Ground Speed

\$GPVTG,309.62,T,,M,0.13,N,0.2,K*6E

| Name | Example | Units | Description |
|------------|---------|---------|----------------------------|
| Message ID | \$GPVTG | | VTG protocol header |
| Course | 309.62 | degrees | Measured heading |
| Reference | T | | True |
| Course | | degrees | Measured heading |
| Reference | M | | Magnetic |
| Speed | 0.13 | knots | Measured horizontal speed |
| Units | N | | Knots |
| Speed | 0.2 | Km/hr | Measured horizontal speed |
| Units | K | | Kilometers per hour |
| Checksum | *6E | | |
| <CR><LF> | | | End of message termination |

2.2 NMEA Input Command

A). Set Serial Port ID:100 Set PORTA parameters and protocol

This command message is used to set the protocol(SiRF Binary, NMEA, or USER1) and/or the communication parameters(baud, data bits, stop bits, parity). Generally,this command would be used to switch the module back to SiRF Binary protocol mode where a more extensive command message set is available. For example,to change navigation parameters. When a valid message is received,the parameters will be stored in battery backed SRAM and then the receiver will restart using the saved parameters.

Format:

```
$PSRF100,<protocol>,<baud>,<DataBits>,<StopBits>,<Parity>*CKSUM
<CR><LF>
```

| | |
|------------|---|
| <protocol> | 0=SiRF Binary, 1=NMEA, 4=USER1 |
| <baud> | 1200, 2400, 4800, 9600, 19200, 38400 |
| <DataBits> | 8,7. Note that SiRF protocol is only valid f8 Data bits |
| <StopBits> | 0,1 |
| <Parity> | 0=None, 1=Odd, 2=Even |

Example 1: Switch to SiRF Binary protocol at 9600,8,N,1

```
$PSRF100,0,9600,8,1,0*0C<CR><LF>
```

Example 2: Switch to User1 protocol at 38400,8,N,1

```
$PSRF100,4,38400,8,1,0*38<CR><LF>
```

**Checksum Field: The absolute value calculated by exclusive-OR the 8 data bits of each character in the Sentence, between, but excluding “\$” and “*”. The hexadecimal value of the most significant and least significant 4 bits of the result are converted to two ASCII characters (0-9,A-F) for transmission. The most significant character is transmitted first.

**<CR><LF> : Hex 0D 0A

B). Navigation Initialization ID : 101 Parameters required for start

This command is used to initialize the module for a warm start, by providing current position (in X, Y, Z coordinates) ,clock offset, and time. This enables the receiver to search for the correct satellite signals at the correct signal parameters. Correct initialization parameters will enable the receiver to acquire signals more quickly, and thus, produce a faster navigational solution.

When a valid Navigation Initialization command is received, the receiver will restart using the input parameters as a basis for satellite selection and acquisition.

Format :

\$PSRF101,<X>,<Y>,<Z>,<ClkOffset>,<TimeOfWeek>,<WeekNo>,<chnlCount>,<ResetCfg>
*CKSUM<CR><LF>

| | |
|---------------|---|
| <X> | X coordinate position INT32 |
| <Y> | Y coordinate position INT32 |
| <Z> | Z coordinate position INT32 |
| <ClkOffset> | Clock offset of the receiver in Hz, Use 0 for last saved value if available. If this is unavailable, a default value of 75000 for GSP1, 95000 for GSP 1/LX will be used. INT32 |
| <TimeOf Week> | GPS Time Of Week |

UINT32

<WeekNo> GPS Week Number
UINT16
(Week No and Time Of Week calculation from
UTC time)

<chnlCount> Number of channels to use.1-12. If your CPU
throughput is not high enough, you could decrease
needed throughput by reducing the number of
active channels
UBYTE

<ResetCfg> bit mask
0x01=Data Valid warm/hotstarts=1
0x02=clear ephemeris warm start=1
0x04=clear memory. Cold start=1
UBYTE

Example: Start using known position and time.

```
$ PSRF101,-2686700,-4304200,3851624,96000,497260,921,12,3*7F
```

C). Set DGPS Port ID:102 Set PORT B parameters for DGPS input

This command is used to control Serial Port B that is an input only serial port
used to receive

RTCM differential corrections.

Differential

receivers may output corrections using different
communication parameters.

The default

communication parameters for PORT B are 9600

Baud, 8data bits, 0 stop bits, and no parity.

If a DGPS

receiver is used which has different communication parameters, use this command to
allow the receiver to correctly decode the data. When a valid message is received, the
parameters will be stored in battery backed SRAM and then the receiver will restart using
the saved parameters.

Format:

```
$ PSRF102,<Baud>,<DataBits>,<StopBits>,<Parity>*CKSUM<CR><LF>
```

| | |
|------------|---------------------------------|
| <baud> | 1200,2400,4800,9600,19200,38400 |
| <DataBits> | 8 |
| <StopBits> | 0,1 |
| <Parity> | 0=None,Odd=1,Even=2 |

Example: Set DGPS Port to be 9600,8,N,1
 \$ PSRF102,9600,8,1,0*12

D). Query/Rate Control ID:103 Query standard NMEA message and/or set output rate

This command is used to control the output of standard NMEA message GGA, GLL, GSA, GSV, RMC, VTG. Using this command message, standard NMEA message may be polled once, or setup for periodic output. Checksums may also be enabled or disabled depending on the needs of the receiving program. NMEA message settings are saved in battery backed memory for each entry when the message is accepted.

Format:

\$ PSRF103,<msg>,<mode>,<rate>,<cksumEnable>*CKSUM<CR><LF>

| | |
|---------------|--|
| <msg> | 0=GGA,1=GLL,2=GSA,3=GSV,4=RMC,5=VTG |
| <mode> | 0=SetRate,1=Query |
| <rate> | Output every <rate>seconds, off=0,max=255 |
| <cksumEnable> | 0=disable Checksum,1=Enable checksum for specified message |

Example 1: Query the GGA message with checksum enabled
 \$ PSRF103,00,01,00,01*25

Example 2: Enable VTG message for a 1Hz constant output with checksum enabled
 \$ PSRF103,05,00,01,01*20

Example 3: Disable VTG message
 \$ PSRF103,05,00,00,01*21

E). LLA Navigation Initialization ID:104 Parameters required to start using Lat/Lon/Alt

This command is used to initialize the module for a warm start, by providing current position (in Latitude, Longitude, Altitude coordinates), clock offset, and time. This enables the receiver to search for the correct satellite signals at the correct signal parameters. Correct initialization parameters will enable the receiver to acquire signals more quickly, and thus, will produce a faster navigational solution.

When a valid LLANavigationInitialization command is received, the receiver will restart using the input parameters as a basis for satellite selection and acquisition.

Format:

\$ PSRF104,<Lat>,<Lon>,<Alt>,<ClkOffset>,<TimeOfWeek>,<WeekNo>,<ChannelCount>,<ResetCfg>*CKSUM<CR><LF>

| | |
|-------------|---|
| <Lat> | Latitude position, assumed positive north of equator and negative south of equator float, possibly signed |
| <Lon> | Longitude position, it is assumed positive east of Greenwich and negative west of Greenwich Float, possibly signed |
| <Alt> | Altitude position float, possibly signed |
| <ClkOffset> | Clock Offset of the receiver in Hz, use 0 for last saved value if available. If this is unavailable, a default value of 75000 |

for GSP1, 95000 for GSP1/LX will be used.

| | | |
|----------------|---------------------------------|---|
| | INT32 | |
| <TimeOfWeek> | GPS Time Of Week | |
| | UINT32 | |
| <WeekNo> | GPS Week Number | |
| | UINT16 | |
| <ChannelCount> | Number of channels to use. 1-12 | |
| | UBYTE | |
| <ResetCfg> | bit mask | 0x01=Data Valid warm/hot starts=1 0x02=clear ephemeris warm start=1 0x04=clear memory. Cold start=1 |
| | UBYTE | |

Example: Start using known position and time.

\$ PSRF104,37.3875111,-121.97232,0,96000,237759,922,12,3*37

F). Development Data On/Off ID:105 Switch Development Data Messages On/Off

Use this command to enable development debug information if you are having trouble getting commands accepted. Invalid commands will generate debug information that should enable the user to determine the source of the command rejection. Common reasons for input command rejection are invalid checksum or parameter out of specified range. This setting is not preserved across a module reset.

Format: \$ PSRF105,<debug>*CKSUM<CR><LF>

<debug> 0=Off,1=On

Example: Debug On \$ PSRF105,1*3E

Example: Debug Off \$ PSRF105,0*3F